




ANA-U GmbH  
Moosgrabenstraße 32  
8200 Gleisdorf  
Austria

Tel: +43 3112 36841  
Fax: +43 3112 57416  
e-Mail: [info\(at\)ana-u\(dot\)com](mailto:info(at)ana-u(dot)com)

# ANA-U CompatibilityBox

## User Manual



Version: 1.2  
Date: 01.February 2011  
Author: Stefan Strobl

© ANA-U 2011

Commercial register number: FN356032b  
Commercial register Graz  
UID-Number: ATU66104547

## Contents

Versionhistory.....	1
Restrictions .....	1
Disclaimer of Warranties .....	1
Disclaimer of Damages .....	1
Trademarks .....	1
General informationen.....	2
DIL-Settings.....	3
Plug connections.....	4
Pin assignment.....	5
Command description.....	6
Used conventions for command description .....	6
Command overview:.....	7
General commands:.....	7
Status commands:.....	7
Font and character commands:.....	7
Print and erase commands:.....	8
Card transport commands:.....	8
Barcode commands:.....	8
Special commands:.....	8

## **Versionhistory**

Version 1.0 – 27.September 2010:

- Document created

Version 1.1 – 10.December 2010:

- Dil-Settings added

Version 1.2 – 01.February 2011:

- Connectors added

## **Restrictions**

You may not a) cause or permit reverse engineering, disassembly, decompilation or alteration of this software; b) remove any product identification, copyright notices, or other notices or proprietary restrictions from this software; c) copy the documentation accompanying the software.

## **Disclaimer of Warranties**

The software is supplied "AS IS". ANA-U disclaims all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The user must assume the entire risk of using the software.

## **Disclaimer of Damages**

ANA-U assumes no liability for damages, direct or consequential, which may result from the use of this software, even if ANA-U has been advised of the possibility of such damages. Any liability of the seller will be limited to refund the purchase price.

## **Trademarks**


Microsoft, MS-DOS, Windows, Windows NT, Windows 95, Windows 98, Windows Me, Windows 2000, Windows XP, ActiveX, Internet Explorer and various associated logos are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other trademarks are the property of their respective owners.


## General informationen

The ANA-U CompatibilityBox allows you to replace the CX-one printer by the SMART-printer.

The existing system as represented below,



can be replaced by the following system, without any changes to the PC-Software.




The ANA-U CompatibilityBox has two serial interfaces. One interface (host) receives the commands for the CX-one printer, and the second (printer) transmits the converted commands to the SMART-printer.

The whole command-set of the CX-one printer is not implemented at this time. This document will give an overview of the already implemented commands.

Especially no chip card commands as the transparent mode are implemented. We recommend to use PC/SC to do so.


The ANA-U CompatibilityBox is integrated to the SMART OEM printer chassis.



*Figure 1: Assembly of the ANA-U CompatibilityBox inside the SMART-Printer*


## DIL-Settings

The DIL-Settings are used to configure the function of the CompatibilityBox. The following list will provide an overview of the implemented settings.



DIL1	DIL2	DIL3	DIL4	Function
OFF	OFF	OFF	ON.....	CXone Mode, 57600 Baud
ON	OFF	OFF	ON.....	Not used
OFF	ON	OFF	ON.....	Version CP2 with Contactchip, 9600 Baud
ON	ON	OFF	ON.....	Version Smartmode with CXone LED emulation, 57600 Baud
OFF	OFF	ON	ON.....	20mm partial erase, 57600 Baud
ON	OFF	ON	ON.....	CP2 Emulation, 9600 Baud
OFF	ON	ON	ON.....	CXone with contact chipreader (Card moves to reader-position), 20mm partial erase, 57600 Baud
ON	ON	ON	ON.....	CXone (hopper) with chipreader (Card moves to reader-position), full erase area, 57600 Baud

## Plug connections



SERIAL1.....	Serial Host Interface
FEEDER.....	Serial Feeder Interface
JTAG.....	Debugconnector
SLOT SENSOR.....	Interface to the slot sensor
FEED2.....	Interface to an edge-triggered feeder
LED.....	Interface to LED-Module
DD SENSOR.....	Interface to the direction detection sensor
SERIAL2.....	Serial Printer Interface

## Pin assignment

### FEEDER

PIN Nr.	Function
1	+24V
2	+24V
3	+24V
4	GND
5	GND
6	GND
7	CTS
8	RTS
9	RxD
10	TxD

### SLOT SENSOR

PIN Nr.	Function
1	GND
2	SLOT SENSOR
3	VCC
4	N.U.

### FEED2

PIN Nr.	Function
1	N.U.
2	FEED2
3	N.U.
4	N.U.
5	N.U.
6	+24V
7	GND
8	IN1

### LED

PIN Nr.	Function
1	GREEN
2	YELLOW
3	RED
4	VCC

### DD SENSOR

PIN Nr.	Function
1	GND
2	DD SENSOR
3	VCC
4	N.U.

### SERIAL2

PIN Nr.	Function
1	N.U.
2	N.U.
3	RxD
4	RTS
5	TxD
6	CTS
7	N.U.
8	N.U.
9	VCC
10	GND

## Command description

### ***Used conventions for command description***

To describe functions and commands the following conventions are used in this manual:

- [xx].....Placeholder for a hexadecimal character
- [xx,xx].....Placeholder for two hexadecimal character
- {DATA}.....Placeholder for a Datablock
- [c].....Placeholder for an ASCII-character
- [c,c].....Placeholder for two ASCII-character
- < >.....Command character
  - <ESC>...Character Escape (Hexadecimal: 0x1b)
  - <CR>....Carriage return (Hexadecimal: 0x0d)
  - \_.....Character Space (Hexadecimal: 0x20)



## Command overview:

The following commandlist will provide an overview of the implemented commands of the CX-one printer in the ANA-U CompatibilityBox.

The complete detailed command-description can be found in the "CX-one Programmers Manual V1.8".

## General commands:

Command	Params	Description
<ESC>1		Enable printer
<ESC>2		Disable printer
<ESC>3		Return card
<ESC>r	[c]	Reset printer
<ESC>\$R		Reboot
<ESC>\$OI	[c,c,c]	Eraseenergy offset
<ESC>\$Op	[c,c,c]	Printenergy offset
<ESC>\$Oh	[c,c,c]	Printhead contact pressure offset
<ESC>MI	0	Read printenergy offset
<ESC>P		Paperticketmode

## Status commands:

Command	Params	Description
<SUB>		Brief status
<ESC>A		Printhead status
<ESC>a		Firmware code
<ESC>?		Printer status

## Font and character commands:

Command	Params	Description
<ESC>C		Select font 1 (small)
<ESC>D		Select font 2 (medium)
<ESC>E		Select font 3 (large)
<ESC>b		Print double width characters
<ESC>w		Print double height characters

## Print and erase commands:

Command	Params	Description
<FF>		Start printing
<ESC>d	[c,c,c,c,c,c]	Limit print area
<ESC>e	[c,c,c,c,c,c]	Limit erase area
<ESC>G	[xx]{DATA}	Send graphic data
<ESC>N		Reset 90° rotation
<ESC>O		Rotate print image 90°
<ESC>T		Rotate print image 180°
<ESC>U		Reset 180° rotation
<ESC>X	[c]	Windowsmode
<ESC>x	[c,c]	Set X-Position
<ESC>y	[c,c,c]	Set Y-Position
<ESC>\$a	[c,c,c,c,c,c,c,c,c,c,c]	Set partial erase

## Card transport commands:

Command	Params	Description
<ESC>c		Get card from feeder
<ESC>J	[xx]	Micro line feed
<ESC>j	[xx,xx,xx]	Microstep forward
<ESC>k	[xx,xx,xx]	Microstep backward

## Barcode commands:

Command	Params	Description
<ESC>z	[c,c] {DATA} <CR>	Print barcode

## Special commands:

Command	Params	Description
<ESC>#		Read direction detection